

OPERATION MANUAL

B+B
SENSORS

Controller N321

Description



Content

Foreword	02
General Information	02
Symbols Employed	03
Warning Signs	03
Safety Instructions	04
Intended Use	04
Disposal	04
1. Product Description	05
1.1. Scope of delivery	04
1.2. Variations	04
1.3. Identification	04
1.4. Description of the buttons on the front of the Controller	05
1.5. Terminals	05
2. Operations	05
2.1. Level 1 - Setpoint Adjustment	06
2.2. Level 2 - Configuration - Parameters configuration Level	06
2.3. Level 3 - Calibration level	07
3. Working with the controller	07
3.1. Configuration Protection	07
3.2. Configuration Protection Usage	08
3.3. The Master-Password	08
4. Error messages	08
5. Electrical wiring	08
6. Technical data	09
Questions	09



OPERATION MANUAL



Controller N321

Foreword

Dear customer,

We thank you for having purchased the controller N321 and we are very glad that you decided to buy a product of **B+B Thermo-Technik GmbH**. We hope this product will fully satisfy you and will assist you effectively in your work. This Device has been developed to be technically highly up-to-date and has been designed in accordance with the regnant European and German national directives and rules. For a proper and effective usage of the product the customer shall observe the following Operating Instructions. In the case that against one's expectations any trouble occurs which you can not resolve yourself, please contact our service centers or our authorized dealer. We will provide you rapid and competent help to minimize the risk of long time outfalls.

The following operating Instruction is an indispensable part of this Product. It contains important advices for the starting up and further use of the device.

General information

This Operation Manual is intended to serve as an aid in the proper setup, installation and operating of the B+B product.

All essential details of the equipment and all actions required on the part are clearly presented and explained. We thus ask that you read this manual carefully before proceeding to work with the equipment. Keep this manual available for ready reference in a convenient and conspicuous location near the equipment.

Symbols employed

Sign	Meaning	Notice
	Advice	It is necessary to read the following advices before using the product. The used symbols in the manual acts first of all as eye catcher for security risks. The symbols do not replace the security advices. The text must be read completely.
	Necessarily to observe	This symbol designates important advices and tips which are necessary for the success of a procedure. They have to be followed in order to get good results.

Warning signs

Sign	Meaning
	This symbol advises the user of danger for persons, material or environment. The text gives information that must be necessarily followed to avoid any risks
	Caution against hot surfaces (BGV A8, GUV-V A8/W26) and hot liquids or substances
	Caution against liquids and hot substances
	Caution against dangerous explosive substances (BGV A8, GUV-V A8/W02)
	Caution against moving machines (W29) Caution against moving parts
	Caution against electromagnetic fields (BGV A8, GUV-V A8/W12)
	Caution against severe cold (BGV A8, GUV-V A8/W17ice)



OPERATION MANUAL



Controller N321

	Caution against dangerous high electrical voltage (BGV A8, GUV-V A8/W08)
	Caution against dangerous explosive atmosphere (BGV A8, GUV-V A8/W21)
	Electronic waste

Safety instructions

For damages caused by failure to observe these safety and operating instructions, B + B Thermo-Technik GmbH is not liable.

This device has been designed and tested in accordance to the safety regulations for electronic devices.

However, its trouble-free operation and reliability cannot be guaranteed unless the standard safety measures and special safety advises given in this manual will be adhered to when using it.

Trouble-free operation and reliability of the device can only be guaranteed if it is not subjected to any other climatic conditions than those stated under "Specification".

If the device is transported from a cold to a warm environment condensation may result in a failure of the function. In such a case make sure the device temperature has adjusted to the ambient temperature before trying a new start-up.

If device is to be connected to other devices the circuitry has to be designed most carefully. Internal connection in third party devices (e.g. connection GND and earth) may result in not-permissible voltages impairing or destroying the device or another device connected.

Warning:

Only devices with mains input: If device is operated with a defective mains power supply (e.g. short circuit from mains voltage to output voltage) this may result in hazardous voltages at the device (e.g. at sensor socket).

If there is a risk whatsoever involved in running it, the device has to be switched off immediately and to be marked accordingly to avoid re-starting. Operator safety may be at risk if:

- there is visible damage to the device
- the device is not working as specified
- the device has been stored under unsuitable conditions for a longer time

In case of doubt, please return device to manufacturer for repair or maintenance.

Caution:

Do not use these product as safety or emergency stop devices, or in any other application where failure of the product could result in personal injury or material damage. Failure to comply with these instructions could result in death or serious injury and material damage.

Intended Use

The use of the unit in fields other than those indicated under "SAFETY INSTRUCTIONS" is not allowed for safety reasons.

This instruction manual does not at all substitute any additional instruction manual of connected accessory!

Disposal

This unit has been marked in accordance with the European Directive 2002/96/EC on waste electrical and electronic equipment (WEEE)

At the end of its operating life-time, dispose of the unit as electrical scrap.

Please ask either **B+B Thermo-Technik GmbH** or your specialist dealer for information on your local collection point.

Within the scope of application of this Directive, **B+B Thermo-Technik GmbH** is responsible for proper disposal of this unit.



OPERATION MANUAL



Controller N321

1. Product description

The Controller N321 is a temperature controller to measure, display and control of temperature. It can be used various types of sensors: Pt1000, Pt100, NTC and thermocouples type K, J and T. The controller can be easily programmed for the application by the user. (cooling or heating). The internal 10 A relay can be used to control of refrigeration compressors or heaters with on / off function. An offset correction of the sensor is provided. The output can be used as control or alarm. The characteristics of the model (sensor-type, sensor-range, power, etc.) can be found on the label located on the controller housing.

2. Scope of delivery

Articlename	Articleno.	Description
Controller N321	0556 0108 xxx	1 x Controller N321, 1x User Manual



1.2. Variations

Articlename	Articleno.
Controller N321 for Pt1000	0556 0108
Controller N321 for NTC 10K incl. Probe (-50 to +120°C)*	0556 0108-01
Controller N321 for Pt100	0556 0108-02
Controller N321 for Thermoelement J, K und T	0556 0108-03
Controller N321 2 x NTC 10K incl. Probe (-50 to +120°C)*	0556 0108-04



*0556 0108-01 and 0556 0108-04 incl. NTC 10K Probe

1.3. Identification

The rating plate is located on the housing of the data logger. Verify that the properties described the same as your job. The following controls can be found on the front page of the data logger.



OPERATION MANUAL




Controller N321

1.4. Description of the buttons on the front of the Controller

-  Programm-key (P)
-  Back-key (R)
-  Up-key
-  Down-key

1.5. Terminals

The figure below shows the controller connections to sensor, main and outputs.



Pt100 with 3 conductors: Terminals 11, 12 and 13 must have the same wire resistance for proper cable length compensation. For 2 wire Pt100, short circuit terminals 12 and 13.

2. Operations

The controller requires the internal parameters to be configured according to the intended use for the instrument. The parameters are organized in 4 groups or levels:

Level	Function
0	Temperature measurement
1	Setpoint adjustment
2	Configuration
3	Calibration

Upon power-up, the N321 display shows for 1 second its firmware version. This information is useful when consulting the factory. Then, the temperature measured by the sensor is shown on the display. This is the parameter level 0 (temperature measurement level).

To access level 1, press  for 1 second until the "SP1" message shows up. Pressing  again to go back to level 0. To access level 2 of parameters, press  for 2 seconds until the "uNT" message is shown. Release the  key to remain in this level. Each new pressing on the  key will advance to the next parameter in the level. At the end of the level, the controller returns to the first level (0). Use the  and  keys to alter a parameter value.

Notes:

- A parameter configuration is saved when the  key is pressed to advance to the next parameter in the cycle. The configuration is stored in a non-volatile memory, retaining its value when the controller is de-energized.
- If no programm key is detected for over 20 seconds, the controller saves the current parameter value and returns to the measurement level.



OPERATION MANUAL



Controller N321

2.1. Level 1 - Setpoint Adjustment

In this level only the Setpoint (SP) parameter is available, alternating the name with its respective value. Adjust the desired temperature for setpoint by clicking on the and keys.

Level	Function
SP (Set Point)	Temperature adjustment for control OUTPUT 1. SP value is limited to the values programmed in SPL and SPk in the programming level (Parameter configuration, level 2).

2.2. Level 2 - Configuration - Parameters configuration Level

Contains the configuration parameters to be defined by the user, according to the system's requirements. Use and keys to set the value. The display alternates the parameter name and respective value.

Level	Function
<i>U n t</i>	Temperature Unit: Selects display indication for degrees Celsius or Fahrenheit. - Temperature in degrees Celsius - Temperature in degrees Fahrenheit
<i>t y P</i>	Input Type: Selects the input sensor type to be connected to the controller. Available only for thermocouple models, allowing selection of types J, K and T. - Thermocouple type J - Thermocouple type K - Thermocouple type T
<i>o F S</i>	Sensor Offset: Offset value to be added to the measured temperature to compensate sensor error.
<i>S P L</i>	SP Low Limit: Lower range for SP. <i>S P L</i> must be programmed with a lower value than <i>S P H</i> .
<i>S P H</i>	SP High Limit: Upper range for SP. <i>S P H</i> must be greater than <i>S P L</i> .
<i>h y t</i>	OUTPUT 1 Hysteresis: Defines the differential range between the temperature value at which the OUTPUT 1 is turned on and the value at which it is turned off. (In degrees).
<i>R c t</i>	Control action for OUTPUT 1: - Reverse: For heating applications. Outputs turn on when temperature is lower than SP. - Direct: For cooling applications. Output turns on when temperature is above SP.
<i>o F t</i> (Off time)	Off time: Defines the minimum off time for control OUTPUT 1. Once OUTPUT 1 is turned off, it remains so for at least the time programmed in <i>o F t</i> . For thermocouple inputs this parameter is not available. This parameter is intended for refrigeration systems where longer compressor life is desired. For heating systems, program <i>o F t</i> to zero. Value in seconds, 0 to 999 s.
<i>o n t</i> (On time)	On time: Defines the minimum on time for control OUTPUT 1. Once turned on, OUTPUT 1 remains so for at least the time programmed in <i>o n t</i> . For thermocouple inputs this parameter is not available. This parameter is intended for refrigeration systems where increased compressor life is desired. For heating systems, program <i>o n t</i> to zero. Value in seconds, 0 to 999 s.
<i>d L t</i> (Delay 1)	Delay time to start control: Upon power-on, control OUTPUT 1 is kept off until the time programmed in <i>d L t</i> is elapsed. Its usage is intended to prevent multiple compressors to start simultaneously after the turn-on of a system with several controllers. Value in seconds, 0 to 250 s.
<i>R d d</i> (Address)	Address: Controllers with the optional RS485 Modbus RTU communication interface have the Add parameter at the Configuration level. Set a unique Modbus address for each equipment connected to the network. Address range is from 1 to 247.



Controller N321

2.3. Level 3 - Calibration Level

The controller is factory calibrated. The following parameters should be accessed only by experienced personnel. To enter this cycle, the **P** key must be kept pressed for 4 seconds.

Don't press the  and  keys if you are not sure of the calibration procedures. Just press the **P** key a few times until the temperature measurement level is reached again.

Level	Function
PAS	Password: Enter the correct password to unlock write operations for the parameters in the following levels.
CAL	Calibration low: Offset value of the input. It adjusts the lower measurement range of the sensor.
CAH	Calibration High: Gain calibration. It adjusts the upper measurement range of the sensor.
CJL	Cold Junction Offset calibration: This parameter is available only for thermocouple.
FAC	Factory Calibration: Restores factory calibration parameters. Change from 0 to 1 to restore the calibration parameters with factory values.
PrE	Protection: Defines the levels of parameters that will be password protected. See „Configuration Protection“ for details.
PAC	Password Change: Allows changing the current password to a new one. Values from 1 to 999 are allowed.
Sr2	Serial number: First part of the controller electronic serial number.
Sr1	Serial number: Second part of the controller electronic serial number.
Sr0	Serial number: Third part of the controller electronic serial number.

3. Working with the Controller

The Controller N321 energizes the output relay such as to maintain the process temperature on the setpoint value defined by the user. The output status led P1 signals when the control output is on.



3.1. Configuration Protection

A protection system to avoid unwanted changes to the controller parameters is implemented. The level of protection can be selected from partial to full. The following parameters are part of the protection system:

PR5: When this parameter is presented, the correct password should be entered to allow changes of parameters in the following levels.

PrE: Defines the level of parameters that will be password protected:

1. Only calibration level is protected (factory configuration);
2. Calibration and Configuration levels are protected;
3. All levels are protected: Calibration, configuration and setpoints.

PAC: Parameter to define a new password. The password is located in the calibration level, and can only be changed by a user that knows the current password. Valid passwords are in the range 1 to 999.

OPERATION MANUAL



Controller N321

3.2. Configuration Protection Usage

PAS-parameter:

PAS-parameter is displayed before entering a protected level. If the correct password is entered, parameters in all following levels can be changed. If a wrong or no password is entered, parameters in the following levels will be read only.

Important notes:

1. After five consecutive attempts to enter a wrong password, new tentative will be blocked for the next 10 minutes. If the current valid password is unknown, the master password can be used only to define a new password for the controller.
2. The password for a brand new device is 111.

3.3. Master-Password

The master password allows user to define a new password for the controller, even if the current password is unknown. The master password is based on the serial number of the controller, and calculated as following:

[1] + [higher digit of SN2] + [higher digit of SN1] + [higher digit of SN0]
for example the master password for the device with serial number 987123465 is: 1 9 3 6
as follows: $1 + 5n2 = 987$; $5n1 = 123$; $5n0 = 465 = 1 + 9 + 3 + 6$

How to use the master password:

1. Enter the master password value at „PaS“ prompt.
2. Go to PA(parameter and enter the new password, which must not be zero (0).
3. Now you can use this new password to access all controller parameters with modify rights.

4. Error Messages

Sensor measurement errors force the controller outputs to be turned off. The cause for these errors may have origin in a bad connection, sensor defect (cable or element) or system temperature outside the sensor working range. The display signs related to measurement errors are shown below:

	Measured temperature exceeded maximum allowed range for the sensor. Broken Pt1000 or T/C . Short circuited NTC sensor.
	Measured temperature is below minimum measurement range of the sensor. Short circuited Pt1000 or T/C . Broken NTC .

5. Electrical Wiring

It is important to follow the recommendations below:

- Signal wires should be installed in grounded conduits and away from power or contactor wires.
- The instrument should have its own power supply wires that should not be shared with electrical motors, coils, contactors, etc.
- Installing RC filters (47 R and 100 nF, series combination) is strongly recommended at contactor coils or any other inductors.
- System failure should always be taken into account when designing a control panel to avoid irreversible damage to equipment or people.



OPERATION MANUAL



Controller N321

6. Technical Data

Properties	Values
Input Sensor	Thermocouples J, K, T, Pt100, Pt1000 and NTC Note: In the controller with NTC input, a 3 m sensor-cable is bundled with the controller. The cable can be extended up to 200 m
Measuring range	J 0 to 600°C (32 to 1400°F) K -50 to 1000°C (-58 to 1832°F) T -50 to 400°C (-58 to 752°F) Pt100 -50 to 300°C (-58 to 572°F) Pt1000 -200 to 530°C (-328 to 986°F)
Accuracy	Thermocouples J, K and T: $\pm 3^{\circ}\text{C}$ ($\pm 5.4^{\circ}\text{F}$) Pt100: $\pm 0,7^{\circ}\text{C}$ ($\pm 1,3^{\circ}\text{F}$) Pt1000: $\pm 0,7^{\circ}\text{C}$ ($\pm 1,3^{\circ}\text{F}$)
Resolution	from -19.9 to 199.9°C display units with NTC, Pt100 and Pt1000 = 0.1 from -19.9 to 199.9°C display units with Thermocouples = 1
Output 1	Relay SPDT, 1 HP 250 V AC / 1/3 HP 125 V AC (16 A Resistive)
Power supply	100 - 240 V AC ($\pm 10\%$) or 24 V AC/DC Mains frequency: 50-60 Hz, Power consumption: 5 VA Caution: Check the power supply specification before energizing the controller
Environment	Operating temperature: 0 to 40°C (32 to 122°F) Storage temperature: -20 to 60°C (-4 to 140°F) Relative humidity: 20 to 85%, non condensing
Case	Polycarbonate UL94, V-2, Suitable wiring: up to 4,0 mm ²
Ingress Protection	Front panel: IP65, Box IP42
Dimensions	74 x 32 x 75 mm
Warm-Up	15 minutes
CE-Conformance	EN 61326-1 according to 2014/30/EU

RS485 digital communication; RTU MODBUS protocol (optional)

Serial interface not isolated from input circuitry.

Serial interface isolated from input circuitry, except in 24 V powered model

Questions

If you still have questions concerning this product of B+B Thermo-Technik GmbH, please do not hesitate to contact us at:

B+B Thermo-Technik GmbH
Heinrich-Hertz-Straße 4
D-78166 Donaueschingen
Germany

Tel.: +49 771 83160
Fax: +49 771 831650
E-Mail: info@bv-sensors.com
www.bb-sensors.com

We wish you a successful measuring!

Your Temperature-Partner
B+B Thermo-Technik GmbH

All technical information in this document are proved by us with high accuracy and shall inform you about all application possibilities. This information are not confirmed by us and need to be proved by every user in regard to his intended use of the equipment. All foreign trade mark rights need to be considered.

