

# OPERATION MANUAL

## Field Logger with 512k Memory



### Technical data

Features	
Input:	Thermocouples J, K, T, E, N, R, S and B, Pt100, Pt1000, DC linear scalable
Accuracy :	J, K, T, E, N: 0.2 % of max Ranges $\pm 1$ °C R, S and B: 0.25 % of max Ranges $\pm 3$ °C Pt100, Pt1000 0-20 mA, 4-20 mA, 0-20 mV, 0-50 mV, 0-60 mV, -20-20 mV, 0-5 V, 0-10 V: 0.15 % of max Range
Internal resolution	20,000 Levels (>14 Bits)
Memory	512 k
Measuring rate	Von 550 ms to 950 ms
Outputs (ALM1 and ALM2):	2 x SPDT-NA 3 A / 250 V (3 A / 30 VDC)
CE-Conformance	2014/30/EU
Elektromagnetic Conductivity	EN 61326-1
Electrical Data	
Supply	100...230 VAC, 50/60 Hz
Consumption :	max. 8VA
Operating temperature	+5...+50 °C
Humidity :	Relative Humidity: 80% @ 31 °C,
Communication:	RS485 / USB
Mechanik	
Dimensions W x H x T:	162,5 x 117 x 70mm
Material :	ABS
Protection :	IP20

### Features

FieldLogger is an analog and digital variables data logger module. It has 8 universal analog inputs and 8 digital I/Os. It can act as a Modbus RTU network master and read registers from other slaves in order to log them into memory or make them available on its other interfaces. Capable of performing mathematical operations on the input channels, it has fast reading and logging rates, a large storage memory, accepts SD card and thumb drive and has a full set of connectivity options.

The full version of FieldLogger operating and installation manual is in the product CD. There users can find all needed information for getting the best out of FieldLogger into their application.

### UNPACKAGE

When unpacking, besides this Quick Guide, you will also find:

- One FieldLogger module;
- One USB cable;
- One CD with software, drivers and product documentation.

### INITIAL CONFIGURATION AND SOFTWARE INSTALLATION

FieldLogger configuration is executed through the Configurator application. This application is freely distributed with the equipment and runs under Windows® XP, Vista and 7 operating systems.


Before connecting the FieldLogger to the computer USB port, please install the Configurator application and the USB drivers. In order to make the first configuration, please follow these steps:

1. Unpack the FieldLogger, CD and USB cable.
2. Install the Configurator application in the computer (USB communication drivers will be installed as well).
3. Power on the FieldLogger and connect it to the computer through the USB cable. In case the drivers have not yet been installed and a window pops up indicating that a new hardware has been found, check in the manual the right proceeding to install it.
4. Run the Configurator application and read the equipment configuration. If it succeeds, you are able to configure and use your FieldLogger. On any error, check the manual and follow the hints and instructions given by the Configurator application.

FieldLogger is set with the following factory default configuration:  
RS485 Interface enabled as SLAVE: 19200 bps, no parity, 1 stop bit and Modbus address 1.

- Ethernet Interface disabled.
- Data logging disabled.
- All analog channels disabled.
- All digital channels disabled (all configured as inputs).
- All virtual channels disabled.
- No alarms configured.
- Download via thumb drive disabled.
- HMI access set only for reading.

### ELECTRICAL CONNECTIONS



### Order Infos

FieldLogger 512k	0568 0041	FieldLogger, 512k, 230VAC power supply
HMI	0568 0041-10	Operating interface for 0568 0041
USB – i458 Converter	0568 0040-10	USB Converter to two isolated RS485 Connection
ISO485-2 – RS485/232 Converter	0568 0040-11	RS485 / 232 Dual Converter



0568 0041 zusammen mit 0568 0041-10

